

When you need to control larger equipment with higher amperage, the PXM is the answer. Power Expansion Modules increase the number OR size of the lights, fans, air conditioners and pumps in your growing area that can be “automated”. The PXMs have been designed to expand the capabilities of the Sentinel controllers and timers. You install the PXM by connecting the pre-wired “trigger” cable into any controller or timer that is 120 volt. Then locate a suitable circuit and plug in the pre-wired #14 AWG cable into the power outlet of your choice. Plug the devices that are to be controlled into the PXM and you are ready to go.

### Large load devices

### HID lighting example

